

9




FIG. 2





FIG. 3






FIG. 5

LOCAL SENSOR 110





FIG. 6






FIG. 8

AUDIO SOURCE 120 FROM FIG.8 910 RECEIVE DATA PACKET 920 **EXTRACT VOLUME** ADJUSTMENT COMMAND FROM **DATA PACKET** 930 YES DOES THE VOLUME NO NEED TO BE **INCREASED?** 950 940 **INCREASE VOLUME DECREASE VOLUME** RETURN TO STEP 410

FIG. 9




FIG. 10




FIG. 11





FIG. 12



LOCAL SENSOR 110




FIG. 14

AUDIO SOURCE 120





FIG. 15






FIG. 17




FIG. 18